

RedShot Laser Cartridge Instructions



Unscrew the end cap and **remove** the battery insulation disc.

The laser cartridge uses three LR626 batteries which are inserted with the positive side, marked with a "+" sign, facing towards the laser end of the cartridge. Screw the end cap on.

ENSURE THE FIREARM CHAMBER IS EMPTY AND THERE ARE NO ROUNDS IN THE MAGAZINE OR IMMEDIATE AREA

Lock the slide in the open position. Make sure the slide stop is fully engaged because it'll hurt like a sonofa if the slide slams closed on your fingers while inserting the cartridge.

With the muzzle pointing downward, insert the laser cartridge into the chamber and push it firmly in place. Release the slide lock allowing the slide to fully close with the laser cartridge in the chamber.

Point the firearm in a safe direction and pull the trigger to verify the laser activates. Retract and release the slide to reset the trigger for each shot if the pistol is single action (most striker-fired models).

To remove the cartridge, lock the slide in the open position and insert an unsharpened pencil through the barrel to gently tap that photon spewing marvel outta there.

ALWAYS FOLLOW THE BASIC RULES OF GUN SAFETY!